

pursuit *TC* 420

WEIGHT CONFIGURATIONS

● 10 g

○ 2 g

BALL FLIGHT

High*



* shipped configuration

BALL FLIGHT

Low



Weight adjustments affect how the clubhead moves during the swing. In general, more weight in the toe causes a fade and more weight in the heel causes a draw. Weight in the rear of the club causes the ball to fly higher and weight in the front will cause it to fly lower. Adjustments made with these factors in mind will allow you to control your ball flight for any situation.

BALL FLIGHT

High Draw



BALL FLIGHT

Mid Draw



BALL FLIGHT

Low Draw



BALL FLIGHT

High Fade



BALL FLIGHT

Mid Fade



BALL FLIGHT

Low Fade

